

TOP



EN 361: 2002



Patented

Chest harness for converting a seat harness into a fall arrest harness.

Torse pour transformer un harnais cuissard en harnais d'antichute.

⚠ WARNING

Activities involving the use of this equipment are inherently dangerous.
You are responsible for your own actions and decisions.

- Before using this equipment, you must:
- Read and understand all instructions for use.
- Get specific training in its proper use.
- Become acquainted with its capabilities and limitations.
- Understand and accept the risks involved.





FAILURE TO HEED ANY OF THESE WARNINGS MAY
RESULT IN SEVERE INJURY OR DEATH.


 160 - 200 cm
63 - 78 inch

1. Field of application

Champ d'application

2. Nomenclature



3. Inspection, points to verify

Contrôle, points à vérifier




PPE checking
Vérification EPI

PETZL.COM



4. Compatibility

Compatibilité



Am'D SL



Am'D TL

OK SL

Version 2017

OK TL

Version 2017

OXAN SL

Version 2017

OXAN TL

Version 2017



i

4. Compatibility

Compatibilité

AVAO SIT

AVAO SIT FAST

FALCON

FALCON MOUNTAIN

SEQUOIA SRT




TOP





5. Installing the TOP chest harness

Installation du torse TOP





Installation on the seat harness
Installation sur le harnais cuissard



5. Installing the TOP chest harness
Installation du torse TOP




B. Putting on the body harness
Installation du harnais complet







AVAO SIT
AVAO SIT FAST
FALCON






FALCON MOUNTAIN



SEQUOIA SRT



6. EN 361: 2002 fall arrest harness
Harnais d'antichute EN 361: 2002



Am'D SCREW-LOCK

CE 0082

EN 362 : 2004

IEC TPTC019/2011

	27 kN
	8 kN
	7 kN
	24 mm
	75 g

